

(STOOP.STOOP3) 24081
STOOP THREE ARRIVAL

AL-449 (FAA)


WEST PALM BEACH, FLORIDA

PALM BEACH APP CON
124.6 317.4
BCT AWOS-3
121.125
PBI D-ATIS
123.75

MELBOURNE
115.85 MLB
Chan 105 (Y)

6000
1580
1580
1580
(58)

NOTE: Jet aircraft only.
NOTE: DME required.
NOTE: RADAR required.



PALM BEACH
115.7 PBI
Chan 104

6000

Ldg KPBI/KBCT/06FA

NOTE: Chart not to scale.

ARRIVAL ROUTE DESCRIPTION

MELBOURNE TRANSITION (MLB.STOOP3): From over MLB VOR/DME on MLB R-159 to STOOP.

LANDING ALL AIRPORTS: From STOOP on PALM BEACH VORTAC (PBI) R-359 to cross PBI VORTAC at 6000. Expect RADAR vectors.